


NANO AP Quick Installation Guide

Enjoy the Wi-Fi Anytime and Anywhere!



System Compatibilities

-Windows XP/Windows Vista/Windows 7/
Windows 8.0/Windows 8.1

Technical Support:

USA/ Canada

Toll Free: +1 866 71 network (+1 866 716 3896)

E-mail: usa_support@netis-systems.com

Other Regions:

E-mail: support@netis-systems.com

Appendix A: FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

1.Package Contents

- 1* A1 NANO AP
- 1* Quick Installation Guide




2.Driver Installation

- 2.1. Plug the "NANO AP" into the USB port of your computer.




Note: Please make sure that your computer is already connected to the Internet.


- 2.2. Download and install the "NANO AP" program from <http://ap.netis.cc>.



- 2.3. Click on the button "Turn Wi-Fi On" on the popup program window of your computer.



- 2.4. Setup your own Wi-Fi name and password.



- 2.5. Connect your smartphones or tablets to your Wi-Fi with the password and enjoy the Internet for free!

